

BECKHOFF





Boot Project


- The TwinCAT Boot Project is used on a production machine as the PLC code to be run when TwinCAT starts.
- The Boot Project in TwinCAT3 is Automatically created when the Configuration is “Activated”
- The default location for the Boot Project is C:\TwinCAT\3.1\Boot



- The “Autostart” for the boot project can be found by selecting the name of the PLC Project in the “Solution Explorer”




- Before activating the configuration the folder is empty, after a “Blank Configuration” has been added the follow files and folders are created.




Boot Project

- Adding a PLC project and then Activating the Configuration provides the following




Boot Project

- A Right-Click on the Project Name in the Solution Explorer will provide a context menu that allows for “Activate Boot Project...” this way you can create a boot project without effecting the I/O configuration.
- There is also the option to Enable and Disable the Autostart of the boot project from here




Boot Project - Encryption

- The option to Encrypt the boot project exists in a drop down list and can be accessed by selecting the project name in the solution explorer



Boot Project - Encryption

- The Boot folder holds a zip file that contains the files to recreate the project, all of these files can be opened by adding them as an existing item.
- The PLC folder contains the information of the actual



Boot Project - Encryption

- Removing the PLC folder from C:\TwinCAT\3.1\Boot will remove the boot project.
- If Encryption is enabled, these are the files that are encrypted.
- Encryption is done with Standard AES encryption.
- An encrypted boot project can only be run on its Target System; therefore moving an encrypted Boot folder from one CX to another will no longer function.

Beckhoff Automation GmbH & Co. KG

Headquarters
Huelshorstweg 20
33415 Verl
Germany

Phone: +49 5246 963-0
Fax: +49 5246 963-198
E-Mail: info@beckhoff.com
Web: www.beckhoff.com

© Beckhoff Automation GmbH & Co. KG

All images are protected by copyright. The use and transfer to third parties is not permitted.

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE®, XFC® and XTS® are registered trademarks of and licensed by Beckhoff Automation GmbH. Other designations used in this presentation may be trademarks whose use by third parties for their own purposes could violate the rights of the owners.

The information provided in this presentation contains merely general descriptions or characteristics of performance which in case of actual application do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract.

Beckhoff Automation GmbH & Co. KG

Unternehmenszentrale
Hülshorstweg 20
33415 Verl
Deutschland

Telefon: +49 5246 963-0
Fax: +49 5246 963-198
E-Mail: info@beckhoff.de
Web: www.beckhoff.de

© Beckhoff Automation GmbH & Co. KG

Alle Bilder sind urheberrechtlich geschützt. Die Weitergabe und Nutzung durch Dritte ist nicht gestattet.

Beckhoff®, TwinCAT®, EtherCAT®, Safety over EtherCAT®, TwinSAFE®, XFC® und XTS® sind eingetragene und lizenzierte Marken der Beckhoff Automation GmbH. Die Verwendung anderer in dieser Präsentation enthaltenen Marken oder Kennzeichen durch Dritte kann zu einer Verletzung von Rechten der Inhaber der entsprechenden Kennzeichen führen.

Die Informationen in dieser Präsentation enthalten lediglich allgemeine Beschreibungen bzw. Leistungsmerkmale, welche im konkreten Anwendungsfall nicht immer in der beschriebenen Form zutreffen bzw. welche sich durch Weiterentwicklung der Produkte ändern können. Die gewünschten Leistungsmerkmale sind nur dann verbindlich, wenn sie bei Vertragsabschluss ausdrücklich vereinbart werden.